


Quick start guide

Refer to main instructions before use



Numeric entries. All numeric entries use the same format. Use up and down navigation buttons to increase or decrease value. Use right button to add digit. If decimal point is required use right followed by down navigation button. Use 'Zero' button for minus sign.